


失真单块 说明书

感谢您使用公司产品，在使用本产品之前请仔细阅读本说明书

操作说明



- 直通脚踏开关**
踩下脚踏按键以切换不同的工作状态；
- LED指示灯**
显示DIST-IV的工作状态，当指示灯亮时为效果开启；
- DIST旋钮**
调节失真度；
- Tone旋钮**
调节音色明亮度；
- 模式选择开关**
选择ULTRA模式、EXTRA模式或ORIGINAL模式；
- LEVEL旋钮**
调节输出音量；
- 输入**
1/4"单声道音频接口，信号输入；
- 输出**
1/4"单声道音频接口，信号输出；
- 电源接口**
9V直流电源(外正内负 ⊕ ⊖)；


技术参数

- ◆ 输入：1/4"单声道音接口(阻抗:470kOhms)
- ◆ 输出：1/4"单声道音接口(阻抗:10kOhms)
- ◆ 电源供给：9V直流电流(外正内负 ⊕ ⊖)
- ◆ 工作电流：6mA
- ◆ 尺寸：95(L)*45(W)*48(H)mm
- ◆ 重量：273克(带包装)

DIST-IV Pedal Manual

Thanks for purchasing our products, before operating this product, please read the enclosed operating instructions.

Operating Instructions



- True BYPASS Footswitch**
Push down the footswitch to switch between effects and bypass status.
- ON/OFF LED**
Indicates effects or bypass status of DIST-IV. When the LED is lit up, the effect is on.
- DIST Knob**
Adjust the gain.
- TONE Knob**
Adjust the tone color.
- Mode Switch**
Switch between ULTRA mode, EXTRA mode and ORIGINAL mode.
- LEVEL Knob**
Adjust the volume.
- Input Jack**
1/4" mono audio jack, inputs the signal.
- Output Jack**
1/4" mono audio jack, outputs the signal.
- DC IN Power Jack**
DC 9V regulated AC adapter (Plug polarity is Positive on the barrel and negative in the center ⊕ ⊖)

Specifications

- ◆ Input: 1/4" Monaural Jack (Impedance:470k Ohms)
- ◆ Output: 1/4" Monaural Jack (Impedance: 10K Ohms)
- ◆ Power Supply: DC 9V (Plug polarity is Positive on the barrel and negative in the center ⊕ ⊖)
- ◆ Working Current: 6mA
- ◆ Dimensions: 95(D)*45(W)*48(H)mm
- ◆ Weight: 273g(With box)

尺寸：170*120 mm
正反面，边框线不要印